

EASY CARE & MAINTENANCE

Montage
EUROPEAN OAK™

Casabella
Hardwood

INITIAL CLEANING AFTER INSTALLATION

- 1 Vacuum and/or Mop**
Clean dust and dirt off the floor with a soft brush vacuum cleaner and/or a standard dust mop.
- 2 Mop with WOCA Oil Refresher**
Mix 1 cup of WOCA Refresher Concentrate with 5 quarts of water in a bucket. Mop the entire floor with this mixture using a Terry Cloth mop.
- 3 Let it Dry**
Leave the floor to dry for 4 to 6 hours before allowing foot traffic and placing rugs.



1 Cup of WOCA Refresher Concentrate

5 Quarts of Water

Only Use a Terry Cloth Mop

ROUTINE CLEANING

Use Pre-Mixed WOCA Oil Refresher Spray Bottle
Spray mixture onto the floor and spread evenly with a clean Terry Cloth mop. Leave the floor to dry for 1 to 2 hours before allowing foot traffic and placing rugs.



WOCA Oil Refresher Spray Bottle



Only Use a Terry Cloth Mop

DEMO VIDEO

Visit <https://vimeo.com/103688782>

CARE & MAINTENANCE GUIDELINES

Montage European Oak Floors are finished with a penetrating hardening oil finish that is designed to protect the new beautiful hardwood floor without a top surface film. This allows the wood to give and take moisture in harmony with the environment around it. It also provides a dirt and wear resistant surface on the floor allowing it to last a lifetime without the need to ever sand.

AFTER INSTALLATION

If the floor needs to be covered to prevent wear and dirt penetration due to additional construction, use paper or cardboard. DO NOT tape paper or cardboard to the floor. After all installation work is completed, vacuum the floor, then clean the floor thoroughly using the WOCA Oil-Refresher as instructed below before covering the floor. DO NOT use any tape including Blue Tape or Mineral Spirits when installing natural oiled floors.

INITIAL CLEANING AFTER INSTALLATION

After the floor is installed it is required to clean the floor using 1 cup of WOCA Oil-Refresher mixed with 5 quarts of water (250 ml to 5 liters of water). Mop the floor gently using a wrung cloth mop. The mop should be damp, not wet. EXCESS MOISTURE CAN DAMAGE THE FLOOR. Leave the floor to dry for 4-6 hours before taken into use. Use WOCA Oil-Refresher White on white oiled floors and WOCA Oil-Refresher Natural on all other oiled floors. Please refer to After-Care Matrix below. (PLEASE CONTACT THE MANUFACTURER FOR FURTHER INSTRUCTIONS)

MUST WATCH THE VIDEO TO LEARN HOW TO APPLY WOCA OIL REFRESHER. Please refer to demo video link for guidelines: <https://vimeo.com/103688782>

ROUTINE CLEANING

Perform monthly cleaning by vacuuming or sweeping. When the floor is dirty, use in MIXING RATIO OF HALF A CUP OF WOCA OIL REFRESHER TO 5 QUARTS OF WATER (125 ML TO 5 LITERS OF WATER) or WOCA Oil Refresher Spray Bottle.

Dip the mop into the Oil-Refresher mixture and clean the floor with the light wrung mop. If the floor is very dirty, it is recommended to work with 2 buckets: one with the solution and one with rinse water. Then mop the floor lengthwise of the boards. Leave the solution on the floor briefly in order to dissolve dirt. Remove dirty Oil-Refresher residues with hard wrung mop and then rinse in bucket with rinse water. Always wipe floor with a hard wrung out mop in order to re-establish the protective WOCA Oil-Refresher micro film. Leave surface to dry for 1-2 hours before taken into use. Use WOCA Oil-Refresher White on white oiled floors and WOCA Oil-Refresher Natural on all other oiled floors. Please refer to After-Care Matrix below. Please refer to the demo video link for Oil Refresher guidelines: <https://vimeo.com/103688782>

CARE & MAINTENANCE GUIDELINE MATRIX			
		Initial Cleaning	Routine Cleaning
LAUREL COLLECTION	Milano	Oil Refresher White	Oil Refresher White
	Sardinia	Oil Refresher White	Oil Refresher White
	Genoa	Oil Refresher Natural	Oil Refresher Natural
	Veneto	Oil Refresher Natural	Oil Refresher Natural
	Abruzzo	Oil Refresher Natural	Oil Refresher Natural
BAROQUE COLLECTION	Russo	Oil Refresher Natural	Oil Refresher Natural
	Forli	Oil Refresher Natural	Oil Refresher Natural
	Palma	Oil Refresher Natural	Oil Refresher Natural
	Marche	Oil Refresher White	Oil Refresher White
	Lazio	Oil Refresher White	Oil Refresher White
FERNO COLLECTION	Salerno	Oil Refresher Natural	Oil Refresher Natural
	Valencia	Oil Refresher Natural	Oil Refresher Natural
	Nord	Oil Refresher Natural	Oil Refresher Natural
	Castillian	Oil Refresher Natural	Oil Refresher Natural
	Rhone	Oil Refresher White	Oil Refresher White
	Canelli	Oil Refresher White	Oil Refresher White
	Fiana	Oil Refresher Natural	Oil Refresher Natural
	Pompeii	Oil Refresher Natural	Oil Refresher Natural
	San Marino	Oil Refresher White	Oil Refresher White
Lorenzo	Oil Refresher Natural	Oil Refresher Natural	
PORTOFINO COLLECTION	Sienna	Oil Refresher Natural	Oil Refresher Natural
	Taverna	Oil Refresher Natural	Oil Refresher Natural
	Amalfi	Oil Refresher Natural	Oil Refresher Natural
	Tuscan	Oil Refresher Natural	Oil Refresher Natural
	Terrazzo	Oil Refresher White	Oil Refresher White

FUTURE MAINTENANCE

Natural oil finished floors should never need to be re-sanded. However, over time it is necessary to apply more oil to the floor. Traffic patterns or wear areas can be easily eliminated with this step. Typically in a residential application this is anywhere from 2-5 years after initial use of the floor. WOCA Maintenance Oil provides the floor with additional hard wearing properties. Use WOCA Maintenance Oil White on White oiled floors and Maintenance Oil Natural on all others. Follow directions on the label.

COMMERCIAL APPLICATIONS

General Recommendations:

After installation in commercial areas (high traffic areas) the new floors should be first mopped with WOCA Wood Cleaner 1:40 ratios to prep the floor. Let the floor dry then polish with a coat of WOCA Master Oil and let floor dry 1-2 hours. Work in 250-300sf sections. Using a thick white polish pad, pour a capful of WOCA Master Oil into the center of the white pad and begin buffing the floor. Add small amounts of oil directly to the floor as needed. Once you have buffed the WOCA Master Oil into a section, you must remove the WOCA Master Oil from the surface. Remove any excess WOCA Master Oil on the surface using a cotton cloth underneath a clean white pad. Repeat this process with each section. Ongoing cleaning for commercial areas is WOCA Oil Refresher. However, please contact the local WOCA specialist for a customized cleaning and maintenance schedule.

Display and Showroom floors are great ways to show the beauty and character of natural oiled floors. To ensure the floors last a long time and hold up to the constant flow of traffic in a showroom or model home the Manufacturer recommends treating these floors as a commercial application by using WOCA Master Oil after installation. The Manufacturer believes this is necessary to maintain the beauty and protect the investment. Please refer to WOCA Commercial Care and Maintenance Guideline and recommend contacting WOCA for detailed step by step process.

QUICK TIPS & TRICKS

DO

- Place Felt Protector on moving furniture
- Place door mat in front of main entrance
- Protect flooring by covering wall to wall during construction with 3" overlap to avoid paint, spills, sheet rock dust, etc.
- Make sure any adhesive is immediately wiped off prior to drying

DON'T

- Don't use any tape on the Floor including Blue Tape
- Don't use Mineral Spirits
- Don't leave spills, wipe up immediately
- Don't use Microfiber (use only Cotton or Terry Cloth)

